



Ford 6.4L Powerstroke K16 Fuel System
Installation Manual Ver. 1.0



Please read all instructions thoroughly before starting installation.

We would like to thank you for purchasing our Stage 2 fuel system. This system will allow you to maintain a constant supply of high pressure fuel to run larger injectors and make over 1000 iswhp. Increased power, throttle response, and High Pressure Fuel Pump (HPFP) life will result from the installation of this kit. If you are installing this system for a customer please pass this manual on to your customer.

Note: This system does require installation of parts in hard to access areas and can be time consuming, also the use of specialized tools can be required. Please be patient and take your time. We have tried to provide as much information as possible to enable this installation to be as trouble free as possible. If at any point in this installation you do not feel comfortable please obtain assistance from a qualified technician.

Installation of this kit is best performed by lifting the vehicle's cab. These instructions are based on the cab being lifted. Please refer to included document on body removal and installation

1. Remove the fan assembly and fan shroud from the front of the engine.



2. Remove Serpentine Belt.



3. Remove bolts holding two idler pulleys in place.
4. Using supplied longer bolts and spacers install extra idler pulleys onto existing pulleys.

